






BUTTONS




UNLOCK




BACKLIGHT




MODE SELECTION




B STOPWATCH




TASTEN




Aufschließen




HINTERGRÜNDBELEUCHTUNG




b STOPPUHR




BUTTONS




Descubrir




LUZ TRASERA




b CRONOMETRO




BOTEÕES




Destravar




LUZ




b CRONÔMETRO




c COUNTDOWN




MODE AUSWAHL




c COUNTDOWN




SELECCIÓN DE MODO




c CONTEO REGRESIVO




SELEÇÃO DE MODO




c CONTAGEM REGRESSIVA




a TIMEKEEPING




d ALARM




a ZEITMESSUNG




d ALARMA




a CRONOMETRAJE



d ALARMA




a CONTAGEM




d ALARME




e DUAL TIME




e DUAL ZEIT



e TIEMPO DOBLE




e TEMPO DUPLIO







BOUTONS




Ouvrir




LUMINEUX




CHRONOMETRE



КНОПКИ




Отпереть




ПОДСВЕТ




СЕКУНДОМЕР



TASTI




Sbloccare




Retroilluminazione




CRONOMETRO




按鍵功能




解鎖




冷光




秒表




SELECTION MODE




САСПТАЖ




ВЫБОР МОДЕЛИ




ОБРАТНЫЙ СЧЕТ ВРЕМЕНИ




MODALITÀ DI SELEZIONE




COUNTDOWN




模式選擇




倒計時




CRONOMETRAGE




ALARM




ХРОНОМЕТРИРОВАНИЕ




СИГНАЛИЗАЦИЯ




Cronometraggio




ALLARME



時間



鬧鈴



第二時間

