


MD11237
INSTRUCTION MANUAL
O&Q Division
CITIZEN WATCH CO.


BUTTONS




BACKLIGHT




MODE SELECTION




a TIMEKEEPING




b STOPWATCH




c COUNTDOWN



d ALARM




e DUAL TIME




MD11237
ANLEITUNG
O&Q Division
CITIZEN WATCH CO.


TASTEN




HINTERGRÜNDBELEUCHTUNG




MODE AUSWAHL




a ZEITMESSUNG




b STOPPUHR




c COUNTDOWN



d ALARM




e DUAL ZEIT




MD11237
MANUAL DE INSTRUCCIÓN
O&Q Division
CITIZEN WATCH CO.


BOTONES




LUZ TRASERA




SELECCIÓN DE MODO




a CRONOMETRAJE




b CRONOMETRO




c CONTEO REGRESIVO



d ALARMA



e TIEMPO DOBLE




MD11237
MANUAL DE INSTRUÇÕES
O&Q Division
CITIZEN WATCH CO.


BOTÕES




LUZ




SELEÇÃO DE MODO




a CONTAGEM




b CRONOMETRO




c CONTAGEM REGRESSIVA



d ALARME




e TEMPO DUPLo




MD11237
MANUEL D'INSTRUCTION
O&Q Division
CITIZEN WATCH CO.


BOUTONS




LUMINEUX




SELECTION MODE




a CHRONOMETRAGE




b CHRONOMETRE




c DECOMPTAGE



d ALARM



e DUEL DES TEMPS




MD11237
ПОРЧЕНИЕ
O&Q Division
CITIZEN WATCH CO.


КНОПКИ




ПОДСВЕТ




ВЫБОР МОДЕЙ




a ХРОНОМЕТРИРОВАНИЕ




b СЕКУНДОМЕР




c ОБРАТНЫЙ СЧЕТ ВРЕМЕНИ



d СИГНАЛИЗАЦИЯ



e ДВУЙНОЕ ВРЕМЯ




MD11237
MANUALE DI ISTRUZIONI
O&Q Division
CITIZEN WATCH CO.


TASTI




Retroilluminazione




MODALITÀ DI SELEZIONE




a Cronometro




b CRONOMETRO




c COUNTDOWN



d ALLARME



e DUALTIME




MD11237
說明書
O&Q Division
CITIZEN WATCH CO.


按鍵功能




冷光




模式選擇




a 時間




b 計時表



c 倒計時



d 鬧鈴



e 第二時間

