



MD08174
INSTRUCTION MANUAL
Q&Q Division
CITIZEN WATCH CO.


BUTTONS




BACKLIGHT



MODE SELECTION




a TIMEKEEPING




MD08174
ANLEITUNG
Q&Q Division
CITIZEN WATCH CO.


TASTEN




HINTERGRÜNDBELEUCHTUNG




MODE AUSWAHL




a ZEITMESSUNG




b STOPPUHR




c COUNTDOWN



d ALARM



e DUAL ZEIT



MD08174
MANUAL DE INSTRUCCIÓN
Q&Q Division
CITIZEN WATCH CO.


BOTONES




LUZ TRASERA




SELECCIÓN DE MODO




a CRONOMETRAJE




b CRONOMETRO




c CONTEO REGRESIVO



d ALARMA



e TIEMPO DOBLE



MD08174
MANUAL DE INSTRUÇÕES
Q&Q Division
CITIZEN WATCH CO.


BOTÕES




LUZ




SELEÇÃO DE MODO




a CONTAGEM




b CRONOMETRO




c CONTAGEM REGRESSIVA



d ALARME



e TEMPO DUPLo




MD08174
MANUEL D'INSTRUCTION
Q&Q Division
CITIZEN WATCH CO.


BOUTONS




LUMINEUX




SELECTION MODE




a CHRONOMETRAGE




b CHRONOMETRE




c D'COMPTE



d ALARM




e DUEL DES TEMPS



MD08174
ПОРЧЕНИЕ
Q&Q Division
CITIZEN WATCH CO.


КНОПКИ




ПОДСВЕТ




ВЫБОР МОДЕИ




a ХРОНОМЕТРИРОВАНИЕ




b СЕКУНДОМЕР




c ОБРАТНЫЙ СЧЕТ ВРЕМЕНИ



d СИГНАЛИЗАЦИЯ



e ДВОЙНОЕ ВРЕМЯ




MD08174
MANUALE DI ISTRUZIONI
Q&Q Division
CITIZEN WATCH CO.


TASTI




Retroilluminazione




MODALITÀ DI SELEZIONE




a Cronometro




b CRONOMETRO




c COUNTDOWN



d ALLARME



e DUALTIME




MD08174
說明書
Q&Q Division
CITIZEN WATCH CO.


按鍵功能




冷光




模式選擇




a 時間




b 倒計時



c 倒計時



d 鬧鈴



e 第二時間

