












# USER'S GUIDE

OD14077(SECONDS CARTOON,MULTI FUNCTION SPORT LCD WATCH)


-  Quartz Movement
-  EL Backlight
-  Stopwatch
-  Countdown Timer
-  Chime
-  5 Alarms
-  Dual Time
-  Pacer
-  100 Years Calendar
-  Battery(CR2025)
-  100M Water Resistant
- +SR626SW)**

## ATTENTION

- Never try to open the case or remove its back cover.
- Do not operate buttons underwater.
- Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
- Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
- Avoid exposing the watch to temperature extremes.
- Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
- Avoid to wear the watch in electromagnetic, static conditions.

## BUTTONS


- Button operation are indicated using the letters shown in the illustration.



- A -- Reset
- B -- Mode
- C -- EL Backlight
- D -- Start/Stop


## DISPLAY

- The screen shown in below:



## ADJUST HANDS

- Pull out the crown, turn to adjust the hour and minutes hands;
- Push the crown go back the normal position after the time set;



## MODE SELECTION

- Press "B" to change mode to mode in the following Sequence:  
Timekeeping Mode -- Stopwatch Mode -- Countdown Mode -- Alarm Mode -- Dual Time Mode -- Pacer Mode.


### a TIMEKEEPING

- 12/24H Format;
- Hour, Minutes, Seconds, Month, Date, Day of week;
- 100 years Calendar(2000~2099).




### b STOPWATCH

- 1/100 second unit;
- Measuring range: 0'00"00 ~ 23:59'59".



### c COUNTDOWN

- Countdown range: 23:59'59" ~ 0'00"00.



### d ALARM

- 5 Alarms;
- Hourly time signal;
- The alarm sounds at the preset time each day.



### e DUAL TIME

- The time for other time zone.



### f PACER


- 10 tempo.



## a TIMEKEEPING


### 12/24H Format

- In the timekeeping mode, press "D" to switch between 12/24 formats.



### Time Setting


- In the timekeeping mode press and hold "A" until the seconds to flash; (flashing indicated in set mode)



- Press "D" to reset the seconds;



- Press "B" to change the next selection;



- Press "D" to increase the number, press and hold to increase at high speed;




- Repeat step 3 and 4, the selection in the following sequence:  
Seconds - Hour - Minutes - Year - Month - Date;
- Press "A" to exit the set state, after you set (The day of week is auto displayed in accordance with year, month and date setting).

## BACKLIGHT

- The backlight that uses an EL(electro-luminescent) cause the display to glow for easy reading in the dark.

### Use EL Backlight

- In the timekeeping mode press "C" to illuminate the display about 3 seconds.




## b STOPWATCH


### A Lap Time




1. In the stopwatch mode, press "D" to start the stopwatch;



2. To stop the stopwatch by pressing "D" again;




3. Press "A" to reset the stopwatch.




### Split Time




1. In the stopwatch mode press "D" to start the stopwatch;



2. Press "A" to display the split time, stopwatch timing continues internally;



3. Press "A" to clear the split time and to continue time measurement;




4. Repeat step 2 and 3, you can measure the multi split time;
5. Press "D" to stop the stopwatch.

## c COUNTDOWN


- When the countdown reaches zero, the alarm sounds for about 60 seconds and press any button to break it.

### Countdown Timer Setting


1. In the countdown mode, press "A" the hour to flash; (flashing indicated in set mode)



2. Press "D" to increase the hour, press and hold to increase at high speed;



3. Press "B" to select the minutes;



4. Press "D" to increase the minutes, press and hold to increase at high speed;



5. Repeat step 3 and 4, the selection in the following sequence:  
Hour- Minutes- Seconds;

6. Press "A" to exit the set state, after you set.

### Use Countdown Timer

1. Press "D" to start the countdown;




2. To pause the countdown by pressing "D" again.

## d ALARM


- The alarm sounds at the preset time each day for about 60 seconds, press any button to break it.

### Alarm and Chime

- In the alarm mode, press "C" to select chime, Alarm1 ~ Alarm5.



- In the chime state, press "D" to on/off the chime.




- In the Alarm1 ~ Alarm5 state, press "D" to on/off the alarm.




### Alarm1 Setting


1. In the alarm mode, press "A" the hour to flash (flashing indicated in set mode);




2. Press "D" to increase the hour, press and hold to increase at high speed;



3. Press "B" to select the minutes;



4. Press "D" to increase the minutes, press and hold to increase at high speed;




5. Press "A" to exit the set state, after you set.

- Setting and operation of the Alarm1 ~ Alarm5 are the same.

## e DUAL TIME

### Dual Time Setting

1. In the dual time mode, press "A" the hour to flash; (flashing indicated in set mode)




2. Press "D" to increase the hour, press and hold to increase at high speed;



3. Press "B" to select the minutes;



4. Press "D" to change the minutes; (press once change 30 minutes)



5. Press "A" to exit the set state, after you set.


## f PACER

### Use The Pacer


1. In the pacer mode, the tempo number flash;



2. Press "A" select the tempo in the following sequence:  
10 - 20 - 30 - 40 - 60 - 80 - 120 - 160 - 240 - 320;



3. Press "D" to start;



4. To stop it press "D" again.

