

USER'S GUIDE


OD19137(SECONDS CARTOON, MULTI-FUNCTION SPORT WATCH)

CITIZEN WATCH CO.,LTD.
Q&Q SALES DEPARTMENT

- World Map**
- World Time**
- Stopwatch**
- EL Backlight**
- Countdown Timer**
- Chime**
- 5 Alarms**
- 100 Years Calendar**
- Low power indicator**
- 100M Water Resistant**
- Battery(CR2025)**

BUTTONS

- Button operation are indicated using the letters shown in the illustration.



- A -- Reset
- B -- Mode
- C -- EL backlight / -
- D -- Start / Stop / +

LOW POWER

- If the battery voltage level is insufficient, the icon will appear to remind to replace a new battery.




ATTENTION

1. Never try to open the case or remove its back cover.
2. Do not operate buttons underwater.
3. Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
4. Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
5. Avoid exposing the watch to temperature extremes.
6. Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
7. Avoid to wear the watch in electromagnetic, static conditions.

DISPLAY

- The screen shown in below:



EL BACKLIGHT

- The backlight that uses an EL, cause the display to glow for easy reading in the dark.

Use Backlight

- In the timekeeping mode, press "C" to illuminate the EL about 3 seconds.




MODE SELECTION

- Press "B" to change mode to mode in the following sequence:
Timekeeping Mode → Stopwatch Mode → Countdown Mode → Alarm Mode → World Time Mode.


a TIMEKEEPING

- 12/24H Format;
- Hour, Minutes, Seconds, Day of week, Year, Month, Date;
- 100 years Calendar (2000 ~ 2099).




b STOPWATCH

- 1/100 second unit;
- Measuring range: 0'00"00 ~ 99:59'59".




c COUNTDOWN

- Countdown range: 99:59'59" ~ 0'00"00.




d ALARM

- 5 Alarms;
- Hourly time signal;
- The alarm sounds at the preset time each day.



e WORLD TIME


- The time for other time zone.



a TIMEKEEPING

Time Setting


1. In the timekeeping mode, press and hold "A" until the city code will flash (flashing is indicated in the setting mode);



2. Press "C" or "D" to select the city code, press and hold to adjust at high speed;



3. Press "B" to select the Daylight Saving Time;



4. Press "C" or "D" to turn ON/OFF the Daylight Saving Time.



5. Repeat steps 3 and 4, the selection in the following sequence:
City code → Daylight Saving Time → Seconds → Hour → Minutes → 12/24H Format → Year → Month → Date → Key Tone(ON/OFF);
6. Press "A" to exit the set state after setting (The day of week is automatically displayed in accordance with year, month and date setting).


World Time Form

City code	GMT Differential	City	Other major cities in same time zone
H11	-11		
HNL	-10	Honolulu	
ANC	-9	Anchorage	
LAX	-8	Los Angeles	San Francisco
DEN	-7	Denver	Edmonton
CHI	-6	Chicago	Mexico City
NYC	-5	New York	Washington, Montreal, Lima
CCS	-4	Caracas	Santiago
RIO	-3	Rio de Janeiro	Buenos Aires
HD2	-2		
HD1	-1		
GMT	+0	GMT	
LCN	+0	London	Dublin, Reykjavik, Casablanca, Lisbon
PAR	+1	Paris	Vienna, Brussels, Berlin, Madrid, Rome, Amsterdam, Warsaw, Stockholm
CAI	+2	Cairo	Athens, Jerusalem, Beirut, Damascus, Istanbul, Helsinki
MOW	+3	Moscow	Baghdad, Nairobi, Kuwait
DXB	+4	Dubai	Abu Dhabi
KHI	+5	Karachi	
DEL	+5.5	Delhi	Mumbai, Calcutta
DAC	+6	Dhaka	
BKK	+7	Bangkok	Hanoi, Jakarta
HKG	+8	Hong Kong	Beijing, Singapore, Manila, Taipei, Kuala Lumpur
TYO	+9	Tokyo	Seoul
ADL	+9.5	Adelaide	
SYD	+10	Sydney	Guam
NOU	+11	Noumea	
WLG	+12	Wellington	Auckland


b STOPWATCH

A Lap Time


1. In the stopwatch mode, press "D" to start the stopwatch;



2. To stop the stopwatch by pressing "D" again;




3. Press "A" to reset the stopwatch.




Split Time


1. In the stopwatch mode, press "D" to start the stopwatch;



2. Press "A" to display the split time, stopwatch timing continues internally;



3. Press "A" to clear the split time and to continue time measurement;



4. Repeat step 2 and 3, you can measure the multi split time;


5. Press "D" to stop the stopwatch.

c COUNTDOWN


- When the countdown reaches zero, the alarm sounds for about 10 seconds and press any button to stop it.

Countdown Timer Setting


1. In the countdown mode, press and hold "A" until the hour will flash (flashing is indicated in the setting mode);




2. Press "D" to increase the hour, press "C" to decrease the hour, press and hold to adjust at high speed;



3. Press "B" to select the next selection;



4. Press "D" to increase the number, press "C" to decrease the number, press and hold to adjust at high speed;




5. Repeat steps 3 and 4, the selection in the following sequence:
Hour → Minutes → Seconds;


6. Press "A" to exit the set state after setting.

Use Countdown Timer

1. Press "D" to start the countdown timer;



2. To pause the countdown by pressing "D" again.



3. Press "A" to reset the countdown.

d ALARM


- The alarm sounds at the preset time each day for about 10 seconds, press any button to stop it.

Alarm and Chime

In the alarm mode, press "C" to select chime, Alarm1 ~ Alarm5.



In the chime state, press "D" to on/off the chime.



In the Alarm1 ~ Alarm5 state, press "D" to on/off the alarm.



Alarm1 Setting

1. In the alarm state, press and hold "A" until the hour will flash, (flashing is indicated in the setting mode);



2. Press "D" to increase the hour, press "C" to decrease the hour, press and hold to adjust at high speed;



3. Press "B" to select the minutes;



4. Press "D" to increase the minutes, Press "C" to decrease the minutes, press and hold to adjust at high speed;



5. Press "A" to exit the set state after setting.



- Setting and operation of the Alarm1 ~ Alarm5 are the same.

e WORLD TIME

1. In the world time mode, press "C" to forward select the time zone, press "D" to backward select the time zone, press and hold to adjust at high speed;




2. In the world time mode, press and hold "A" to turn ON/OFF the Daylight Saving Time (except "GMT+0").



SELECT TIAL

In the timekeeping mode, press "D" to select different dials.



4 dials for user to choose.

In the timekeeping mode, press and hold "D" to switch T1 or T2 display.

